



Heinzmann GmbH & Co. KG
Engine & Turbine Management

Am Haselbach 1
D-79677 Schönau
Germany




Phone +49 7673 8208 - 0
Fax +49 7673 8208 - 188
E-mail info@heinzmann.de
www.heinzmann.com

V.A.T. No.: DE145551926

HEINZMANN®
Engine & Turbine Management

Digital Positioning System 2000

StG 2040.xx-SV-PD
and
StG 2080.xx-SV-PD

 ⚠ DANGER	<p>The appropriate manuals must be thoroughly studied before installation, initial start-up and maintenance.</p> <p>All instructions pertaining to the system and safety must be followed in full. Non-observance of the instructions may lead to injury to persons and/or material damage.</p> <p>HEINZMANN shall not be held liable for any damage caused through non-observance of instructions.</p> <p>Independent tests and inspections are of particular importance for all applications in which a malfunction could result in injury to persons or material damage.</p> <p>All examples and data, as well as all other information in this manual are there solely for the purpose of instruction and they may not be used for special application without the operator running independent tests and inspections beforehand.</p> <p>HEINZMANN does not guarantee, neither expressly nor tacitly, that the examples, data or other information in this manual is free from error, complies with industrial standards or fulfils the requirements of any special application.</p>
 ⚠ WARNING	<p>To avoid any injury to persons and damage to systems, the following monitoring and protective systems must be provided:</p> <ul style="list-style-type: none"> – overspeed protection independent of the rpm controller <p>HEINZMANN shall not be held liable for any damage caused through missing or insufficiently rated overspeed protection.</p> <ul style="list-style-type: none"> – thermal overload protection <p>The following must also be provided for alternator systems:</p> <ul style="list-style-type: none"> – Overcurrent protection – Protection against faulty synchronisation for excessively-large frequency, voltage or phase difference – Directional contactor <p>The reasons for overspeeding may be:</p> <ul style="list-style-type: none"> – Failure of positioning device, control unit or its auxiliary devices – Linkage sluggishness and jamming
	<p>The following must be observed before an installation:</p> <ul style="list-style-type: none"> – Always disconnect the electrical mains supply before any interventions to the system. – Only use cable screening and mains supply connections that correspond with the <i>European Union EMC Directive</i> – Check the function of all installed protection and monitoring systems



	<p>Please observe the following for electronically controlled injection (MVC):</p> <ul style="list-style-type: none"> – For common rail systems each injector line must be equipped with a separate mechanical flow-rate limiter. – For unit pump (PLD) and pump-injector unit (PDE) systems, the fuel enable is first made possible by the solenoid valve's control plunger motion. This means that in the event of the control plunger sticking, the fuel supply to the injection valve is stopped.
	<p>As soon as the positioning device receives power, it can actuate the controller output shaft automatically at any given time. The range of the controller shaft or control linkage must therefore be secured against unauthorised access.</p>
	<p>HEINZMANN expressly rejects any implied guarantee pertaining to any marketability or suitability for a special purpose, including in the event that HEINZMANN was notified of such a special purpose or the manual contains a reference to such a special purpose.</p>
	<p>HEINZMANN shall not be held liable for any indirect and direct damage nor for any incidental and consequential damage that results from application of any of the examples, data or miscellaneous information as given in this manual.</p>
	<p>HEINZMANN shall not provide any guarantee for the design and planning of the overall technical system. This is a matter of the operator its planners and its specialist engineers. They are also responsible for checking whether the performances of our devices match the intended purpose. The operator is also responsible for a correct initial start-up of the overall system.</p>

Table of Contents

	Page
1 Safety Instructions and the signal words and symbols used	5
1.1 Safety measures under normal operation.....	6
1.2 Safety measures for maintenance and servicing.....	6
2 Application and function	7
2.1 Proper and intended use.....	7
2.2 Function description	7
3 Functional Block Diagram.....	8
4 Operating Mode.....	9
5 Positioning Control System	10
5.1 Specification	10
5.2 Design and Mode of Operation	12
Actuators StG 2040.XX-SV-PD and 2080.XX-SV-PD.....	12
5.3 Installation	13
5.4 Actuator Specification	13
5.5 Dimensions	14
6 Regulating Linkage	15
6.1 Length of Lever Arm.....	15
6.2 Connecting Linkage.....	15
6.3 Linkage Adjustment for Diesel Engines.....	15
6.4 Linkage Adjustment for Carburettor Engines	16
7 Electrical Connection	17
7.1 Wiring Diagram.....	17
7.2 Connection of Power Supply	18
8 Figure List.....	20
9 Download of Manuals	21

1 Safety Instructions and the signal words and symbols used

This publication offers practical safety instructions to indicate the unavoidable residual risks involved when operating the machine. These residual risks involve hazards to

- Personnel
- Product and machine
- The environment

The primary aim of the safety instructions is to prevent personal injury!

The signal words used in this publication are specifically designed to direct your attention to possible damage extent!



DANGER indicates a hazardous situation the consequence of which could be fatal or severe injuries if it is not prevented.



WARNING indicates a hazardous situation which could lead to fatal injury or severe injuries if it is not prevented.



CAUTION indicates a hazardous situation which could lead to minor injuries if it is not prevented.



NOTICE indicates possible material damage.



Safety instructions are not only denoted by a signal word but also by hazard warning triangles. Red hazard warning triangles indicate immediate danger to life. Yellow hazard warning triangles indicate a possible risk to life and limb. Hazard warning triangles can contain different symbols to illustrate the danger. However, the symbol used is no substitute for the actual text of the safety instructions. The text must therefore always be read in full!

1.1 Safety measures under normal operation



The system may be operated by qualified and authorised personnel only, who are both familiar with the operating instructions and who can carry them out!

Before switching on the system, check and ensure that:

- > only authorised personnel are in the machine's operating range
- > no-one can be injured by the machine starting up

Before each start of the motor:

- > Always check the system for visible damage and ensure it is not put into operation unless it is in perfect condition! Always notify the responsible department immediately about any defects
- > Check and ensure that all safety devices are in proper working condition
- > Remove all material and objectives surplus to requirements from the operating range of the system or motor

1.2 Safety measures for maintenance and servicing



Before starting maintenance or repair work:

- > Block off access to the machine's working area for unauthorised persons! Put up an information board that indicates that such work is underway
- > Switch off main switch for mains supply and secure with a padlock! The key to the padlock must be held by the person carrying out the maintenance or repair work
- > Ensure that all parts that are capable of being touched have cooled down to ambient temperature and have been isolated from the mains
- > Re-fasten loose connections
- > Replace any damaged lines or cables immediately
- > Keep the switch cabinet closed at all times! Access is solely for authorised persons with key/tools
- > Never use a water spray or high-pressure cleaners on switch cabinets and other electrical equipment enclosures for cleaning purposes! Risk of short circuit and corrosion to positioning device

2 Application and function

2.1 Proper and intended use

The positioning devices StG 2040-PD and StG 2080-PD are to be used solely for control applications on engines. They are intended for use in an industrial environment. When operated outdoors, additional protective measures against weather are also required.

Signals are exchanged through electrical signals. Because transmission may be interfered with by external circumstances or influences, the user must provide additional safety devices to match the application case.

In individual cases, the following must be coordinated with the manufacturer HEINZMANN:

- Each use which deviates from the above mentioned
- Modifications to the device
- Use in extreme, ambient conditions that deviate from the specification (dust, temperature, wetness)
- Use under powerful electrical or electromagnetic fields
- Use in aggressive atmospheres or vapours
- Use in potentially explosive areas

A written opinion from the manufacturer must always be procured in the event of any obscurities, queries or missing statement.

2.2 Function description

Positioners show a directly proportional correlation between the position of the actuator output shaft and a command input signal. StG 2040-PD and StG 2080-PD are electrical positioners with rotating output shaft. They are actuated by an external, electrical position set point signal, and thereby automatically regulate the mechanical position of their output shafts. The position set point is transmitted as a current, voltage or PWM signal to each positioning device. For operation the devices must be connected to an external mains supply.

3 Functional Block Diagram




Figure 1: Functional block diagram

4 Operating Mode

The input signal, i.e. the position setpoint for the actuator output shaft is sent to an actual/setpoint comparator receiving the actual value from the actuator feedback. Subsequent signal processing for position control is performed by a microcontrol.

The position control circuit incorporates a 4-quadrant amplifier which allows to drive the actuator electrically in either direction. This ensures optimum utilization of the actuator's rotational force. Together with very low current consumption in steady state operation heat build-up in the actuator also is reduced.

The feedback signal, i.e. the output shaft position signal, is available analogue as a current signal, a voltage signal or as PWM-signal. It can be used as well for further processing as for indicating actuator position.

Due to the programable microcontrol a lot of functions and capabilities of the Digital Positioning System 2000 can be determined by parameterization. This offers various options for the systems setting up and its configuration.

For instance linear output characteristic, range, type and sense of input and output etc. can be adapted to users requirements.

5 Positioning Control System

StG 2040.XX-SV-PD and StG 2080.XX-SV-PD

5.1 Specification

nom. supply voltage	24 V DC
max. voltage	40 V DC
min. voltage	16 V DC
maximum ripple voltage at max. actuator current	10 % at 100 Hz
acceptable voltage drop at max. actuator current	max. 10 % at control unit
fuse protection	8 A (external, by user)
current consumption	approx. 250 mA, additionally current of actuator
steady state variation	±0.25 %.
storage temperature	-40°C to +100°C.
operating ambient temperature	-25°C to +90°C.
humidity	up to 98 %
vibration level	± 1 mm at 1 ... 20 Hz, max. 0.24 m/s at 21 ...63 Hz, max. 5 g at 64 ... 300 Hz

“command”

proportional input	
alternatively :	
current signal	4 ... 20 mA
voltage signal	0 ... 5 V
	0 ... 10 V
PWM	50 ... 500 Hz
	350 Ω input resistance
	100 kΩ input resistance
	20 kΩ input resistance
	100 kΩ input resistance (pull up optional)

“actual position”

proportional output	
alternatively	
current signal	4 ... 20 mA
PWM	50 ... 500 Hz
	max. 220 Ω burden resistance
	lowside switch, 4,7 kΩ pullup
	$U_{rest} < 1 \text{ V at } I_{max}$
	$I_{max} = 0.3 \text{ A}$

“common alarm”

binary output, galvanically insulated

residual voltage when switching

$$U_{\text{rest}} < 3 \text{ V at } I_{\text{max}}$$
$$I_{\text{max}} = 15 \text{ mA}$$

Alarms:

- command out of range
 - actuator in current limitation
 - difference from command to actual position
- when signal < 2 mA or signal > 22 mA

“shut down” binary input

current signal	open	—>	normal operation
voltage signal	> 4mA	—>	stop
input resistance	> 6 V	—>	stop
	$R_i > 500 \Omega$		



NOTE: All specified values for inputs and outputs etc. are standard values. For the Digital Positioning System 2000 is programmable, these values can be adapted and determined specifically to users requirements to a wide range. The system may be operated by qualified and authorised personnel only, who are both familiar with the operating instructions and who can carry them out!

5.2 Design and Mode of Operation

With this type of positioner, a multi-polar magnetized permanent magnet is mounted on the output shaft. Opposite the permanent magnet an armature with the working coils is mounted. When current is applied to the working coils, torque in one direction is generated. Reversing current polarity will generate torque in the opposite direction.

By using special materials and long-term lubricants the positioners are maintenance-free and have a long service life.

The actuator output shaft is provided with a feedback cam for contactless sensing by a probe transmitting the accurate output shaft position to the control unit.

The control unit is installed on the back side of the positioner under a separate cover, opposite of the output shaft journal.

When the actuator is driven against a mechanical stop current limitation will take effect after approx. 20 seconds and reduce current to the actuator to a value sufficiently low to prevent damage to the actuator.

Actuators StG 2040.XX-SV-PD and 2080.XX-SV-PD




Figure 2: Principle of StG 2040.24-SV-P and 2080.22-SV-P

Altogether, this type of positioner offers following advantages:

- High regulating power working in either direction.
- Extremely low current consumption during steady state and relatively low current consumption on changes of load.
- Indifference to slow voltage changes of power supply; abrupt voltage changes, however, will cause governor disturbances.

5.3 Installation

The positioner must be firmly mounted on the engine using a support with stiffened brackets. Vibrating arrangements as may be caused by weak bracket material or missing stiffenings must be avoided by all means as this will increase vibrations and lead to faster wear of positioner and linkage.

5.4 Actuator Specification

	StG 2040.XX-SV-PD	StG 2080.XX-SV-PD
Effective rotation at the output shaft	68°	68°
Max. torque at the governor output shaft	approx. 6.6 Nm	approx. 7.8 Nm
Torque in steady state condition	approx. 3.3 Nm	approx. 4.6 Nm
Response time 0-100 % without load	< 150 ms	< 90 ms
Current consumption maximum current current in steady state condition	approx. 7 A max. 3.5 A	approx. 7 A max. 3.5 A
Ambiente temperature in operation	-25°C up to +90°C	-25°C up to +90°C
Humidity	up to 98 %	up to 98 %
Protection grade	IP 65	IP 65
Weight	approx. 6,5 kg	approx. 8,6 kg

StG 2040.XX-SV-PD



Figure 4: Dimensional drawing StG 2080.XX-SV-PD

6 Regulating Linkage

6.1 Length of Lever Arm

The length of the lever arm is determined in such a way that approx. 90 % of the governor output shaft adjustment angle can be used. Based on this, the rack length L of governors with 68° adjustment angle is calculated as $L = 1.8 a$, "a" being the travel distance of the injection pump or the carburettor.

6.2 Connecting Linkage

The connecting linkage from the governor to the injection pump or the carburettor should be length-adjustable and have a (pressure or tension) elastic link. If the actuators torque is less than 10 Nm, the elastic link is not needed. If possible, joint rod heads in accordance with DIN 648 should be used as connecting links. The linkage must operate easily and without clearance.

In case of friction or backlash in the linkage connecting actuator and injection pump resp. throttle valve no optimal control is possible.

6.3 Linkage Adjustment for Diesel Engines

The length of the connecting linkage is adjusted in such a way that with the governor in stop position the injection pump is set to 0 - 2 fuel marks. (Travel of the injection pump control rack is limited by the governor.)




Figure 5: Example of linkage for diesel engines

The resistance of the pressure elastic link is overcome when the control rack has reached the full load stop and the speed continues to decrease (overload). Furthermore, the elastic link is overcome when stopping via the emergency switch.

6.4 Linkage Adjustment for Carburettor Engines

For carburettor or gas engines, the length of the connecting linkage is adjusted in such a way that with the governor in full load position the throttle valve is completely open. In idling speed position, the elastic link must be slightly overcome. This allows adjustment of the idle screw without changing the governor adjustment.




Figure 6: Example of linkage for gas engines

If carburettor or injection pump are to the left of the governor as opposed to their position on the drawings, then the direction of motion of the elastic link must also be reversed.

7 Electrical Connection

7.1 Wiring Diagram




Figure 7: Example of standard wiring diagram


7.2 Connection of Power Supply

Inappropriate choice of power supply or insufficient battery capacitance or incorrect connection of the power supply line or too small cable sizes of the feed line and the motor line of the positioner are bound have an adverse effect upon the performance of the speed governor. In steady state operation, this will cause a heavy increase of current consumption and unnecessary vibration of the positioner drive. The high current consumption will in its turn lead to overheating of the actuator or the position control unit, and the vibration will result in premature wear of the gear and bearing parts or of the linkage.



NOTE: In altogether, the lifetime of the control system is distinctly reduced by the errors described above

The following figure shows both a wrong and a correct cabling:



1) Coils (e.g. stopping solenoid, gas valve) have to be equipped with a protective circuit to eliminate high inductance voltages. Diode type e.g. 1N4002

Figure 8: Correct Connection of Power Supply

NOTICE

If there are battery chargers with rapid charge mode installed in the plant, the rapid charge mode should not be used during operation.

If there is no battery provided, **it is absolutely necessary** that a three phase power supply or a **stabilized** single phase power supply with at least 24 V DC, 10 Amps output power **be used** as a power source.

NOTICE

The cable sizes and cable lengths described in the wiring diagrams must not be exceeded!

When power supply, battery and cabling have been correctly dimensioned, then on starting the engine or with the positioner operating at maximum current consumption (approx. 6.4 A), a drop of the supply voltage directly at the control unit of approx. 2 Volts maximum only will be admissible.

8 Figure List

Figure 1: Functional block diagram	8
Figure 2: Principle of StG 2040.24-SV-P and 2080.22-SV-P.....	12
Figure 3: Dimensional drawing StG 2040.XX-SV-PD.....	14
Figure 4: Dimensional drawing StG 2080.XX-SV-PD.....	14
Figure 5: Example of linkage for diesel engines.....	15
Figure 6: Example of linkage for gas engines.....	16
Figure 7: Example of standard wiring diagram.....	17
Figure 8: Correct Connection of Power Supply	18

9 Download of Manuals

Technical manuals can be downloaded in pdf-format from our homepage:

www.heinzmann.com

If the desired manual should not be available there, send an e-mail to:

info@heinzmann.de

or write to:

HEINZMANN GmbH & Co. KG

Technische Redaktion

Am Haselbach 1

D-79677 Schönau/Germany

Please include the following information:

- your name
- name and address of your company
- e-mail or address where you want the manuals to be sent to (if different from above)
- item code (as on front page, bottom right) and title of the desired manual
or alternatively the technical data of your HEINZMANN equipment

We would be pleased to receive your comments about the contents and presentation of our publications. Send your comments to the e-mail or address shown above please.